



Troubleshooting Guide

for

Orca Smoke Alarms

Problem	Cause	Solution
Test function not operating.	Battery not installed correctly.	Install battery properly.
	Not holding test button long enough.	Push and hold button for up to 20 seconds or until alarm sounds.
Alarm chirping intermittently as soon as battery is installed.	Alarm has gone direct into programming the test mode.	Leave alarm for 8-15 minutes. Chirping will silence as soon as alarm automatically resets itself.
Alarm keeps chirping intermittently after test function has been performed.	This is a normal procedure.	Leave alarm for 8-15 minutes. Chirping will silence as soon as alarm automatically resets itself.

© ORCA MARKETING May 2009